

HOW TO APPLY FERROFLEX® FERROUS WALLPAPER

With our FerroFlex® ferrous non-woven wallpaper sheets you can turn walls into creative chalkboard or white board surfaces that magnets will attract to. The non-woven material is tear resistant, can be easily applied and can be removed totally dry and re-applied. This product is applied the same as all standard wallpapers but ensure that a heavy-duty paste is used. Ideal in the home for bedrooms and kitchens, and in working environments such as classrooms, restaurants and offices.


PRODUCT OPTIONS:



Matt white wallpaper



Whiteboard wallpaper



Chalkboard wallpaper

1 PREPARE WALLS FOR WALLPAPER APPLICATION

- Protect your surroundings with sheets.
- Make sure your wall is prepared by removing any old wallpaper, ensuring any holes and cracks are filled and are smoothed down after.
- Absorbent surfaces should be treated with a primer before the applying the wallpaper.

2 MEASURE & MARK YOUR WALL

- Measure the height and width of the wall you are wanting to apply your magnetic wallpaper to.
- With your wall measurements, work out how much wallpaper you will require. Our FerroFlex® wallpaper rolls are available in 1 or 5 metre lengths and are 600mm wide. If you require more FerroFlex® wallpaper, we also have 2 x 5 metre rolls and 6 x 5 metre rolls.
- Along to the top, middle and bottom of your wall measure and mark 600mm. Then from top to bottom join the dots lightly in pencil. Make sure the lines are level.

3 PREPARE WALLPAPER

- Measure the wallpaper to the desired length and cut to size. Our sheets can easily be cut with scissors, a Stanley knife or a guillotine

4 APPLY ADHESIVE

- You will require heavy duty ready mixed wallpaper paste.
- Apply one or two coats of the paste to the wall with a roller or brush.

5 APPLY MAGNETIC WALLPAPER

- Starting in a corner of the wall, roll the wallpaper out, using your markings as a guide.
- Carefully roll the wallpaper out whilst pushing any air and excess paste out from behind the material as you go.
- Once rolled out with a wallpaper spatula, use consistent and strong pressure and go back over the wallpaper to ensure all air bubbles and excess adhesive have been pushed out to the edges.
- Next, carefully add the neighbouring wallpaper. Start in the corner where the wallpaper will join and slowly roll neatly along the neighbouring wallpaper.
- Repeat this process for the entire installation of the wallpaper.
- Once installation is complete, wipe the entire surface clean with a damp cloth to remove any excess adhesive residue. Finally inspect for any air bubbles.

ALLOW TO DRY

- ## 6
- Leave the wallpaper to cure to your wall for 48 hours. Once dried your wallpaper is ready to use and showcase your creativity and attract magnets to!

