



magnets4  
your body

# **INSTRUCTIONS FOR USING LINK REMOVAL TOOL**


The blue plastic tool included with your new magnets4 magnetic bracelet is used to remove and replace the small pins that hold each link in the bracelet together. By using the tool, you can adjust the size of the bracelet to the desired length.

## **STEP ONE**

Unwind the handle by turning counter-clockwise to retract the arm far enough to place the bracelet in the channel.


## STEP TWO

Place the bracelet face up in the channel and align the pin you wish to remove with the arm.




## STEP THREE

Holding the bracelet in place with one hand, turn the handle clockwise to extend the arm taking care to ensure the end of the arm is aligned with the pin.



## STEP FOUR

Continue turning the arm to push the pin out of the other side of the link. Continue until there is enough of the pin showing to be able to pull it out.



## STEP FIVE

Repeat steps one to four to remove the pin at the opposite end of the links you wish to remove.

- 1) Turn handle to retract arm.
- 2) Insert bracelet and align the pin and arm.
- 3) Turn handle clockwise to extend the arm.
- 4) Push the pin out until enough is showing to pull.

## STEP SIX

Take the two pieces of bracelet that need attaching back together and align the holes of the end links. Push one of the pins that you removed back into the holes, securing the two pieces together. Alternatively, you can use the removal tool to push the pin back into place by aligning the partly inserted pin and arm and turning the handle clockwise.

