

HOW TO INSTALL MC663419(BK)

These double push to close magnetic catches with plastic casing are perfect for providing a secure closure and ease of opening for cupboard and wardrobe doors. Due to the 2x spring push mechanism, handles are not required on doors, leaving a clean and stylish look to cupboards and wardrobes. Catch is provided with attracting steel striking plate. Screws for magnetic catch sold separately.

Your Catch includes;

- Magnetic catch
- Striking plate



Easy to install



Premium design



Secure hold

1

Step 1

Select your desired position on the cupboard frame where you would like the catch to be installed. We advise placing this in the corner of the cupboard, either on the side or bottom of the frame where you are most likely to push open the cupboard door from (if using without handles).

2

Step 2

Once you have marked your desired position on the cupboard frame, place the catch in position and screw into place (screws sold separately).

3

Step 3

Once the catch is fixed in position, line up the steel plates and screw into place (screws sold separately).

Once installed, the magnetic push catch will allow you to easily push to open cupboard/ wardrobe doors with ease, and the secure magnetic face will allow you to securely close.

If you require any further assistance or advice on our range of magnetic catches, please call out experts on **0800 488 0288** or email sales@first4magnets.com