


HOW TO INSTALL YOUR MAGNETIC KNIFE RACK

Magnetic Knife Rack with Back Plate


Installation guide for F4MMKR-BK, F4MMKR-WM, F4MMKRS-BK, F4MMKRS-GO-1 & F4MMKRS-SI

Our premium range of magnetic knife racks provide the perfect stylish solution to organise and display kitchen knives and other utensils. With simple installation and easy application, they are a must have for any kitchen space.

To remove the back plate from the knife rack housing, carefully pull the plastic tabs.




1 Step One



Using a spirit level to ensure it is straight, place the backing plate to the desired position and mark out the holes.

Parts Included;

- A- Knife Rack
- B- Steel Plate
- C- Screws and Wall Plugs




2 Step Two




Using the marks as a guide, drill holes and insert the raw plugs into place.

3 Step Three



Place the backing plate back in place over the holes and apply the screws to secure the plate in position.

4 Step Four



Once the plate is securely applied and any residue is wiped away, carefully mount the knife rack housing onto the plate. When mounting, ensure care is taken and fingers are not placed between the plate and knife rack.

SAFETY WARNING – MAGNETIC KNIFE RACKS INCLUDE STRONG MAGNETS, PLEASE INSTALL WITH CARE.

If you require any further assistance or advice on our range of magnetic knife racks, please call our experts on

0800 488 0288 or email sales@magnetexpert.com